

7 SPILL PROCEDURES & WASTE DISPOSAL

Alodine 1200

SPILL PROCEDURES

Transfer any excess to a clean polyethylene container. Treat remaining residue with a dilute solution of sodium metabisulfite to reduce chrome. neutralize with lime to pH 7-8.

WASTE TREATMENT

Flush reduced and neutralized material to treatment plant with plenty of water and with approval of regulatory agency.

8 PERSONAL PROTECTION

VENTILATION REQUIREMENTS

GENERAL AREA EXHAUST ☐

LOCAL EXHAUST ☒

NO EXHAUST NECESSARY ☐

PERSONAL PROTECTIVE EQUIPMENT

EYE PROTECTION

Safety goggles

SKIN PROTECTION

Rubber Gloves and aprons

RESPIRATORY PROTECTION

Filter type dust respirator-NIOSH approved

OTHER REQUIRED EQUIPMENT

N/A

9 SPECIAL PRECAUTIONS AND STORAGE

Keep separate from organic materials and reducing agents. Do not breathe dust or get in eyes or on skin. Do not open container in an unventilated space.

PREPARED BY Charles Gruszka

DATE 2/28/86
(rev.)

TITLE Senior Chemist